

SHAFFER ENTERPRISES, LLC

COOL VEST

10 Andrew Drive Suite 200

Stockbridge, GA 30281

Sales & Service 800-345-3176 Fax 678-289-4325

www.coolshirt.net

Surgeon's **COOL VEST**

Temperature Controller Hose – IMPORTANT PLEASE READ

Your **COOL VEST** *Temperature Controller Hose* is equipped with a temperature control valve. The valve, located on the hose, is a roller-style controller that allows the user to adjust the temperature of the **COOL VEST** to meet their particular preferences.

To adjust the temperature of the vest to a *warmer* setting, simply roll the round control wheel downward, allowing it to pinch off the hose line and thus slow the flow of the water to the vest until the desired temperature is reached.

To adjust the temperature of the vest to a *cooler* setting, simply roll the round control wheel upward, allowing less crimping of the hose line and thus speeding up the flow of the water to the vest until the desired temperature is reached. For the *coolest* setting, roll the wheel all the way to the top of the controller to allow full water flow.

Never use the roller to completely stop water flow to the vest. To stop water flow completely, use the ON/OFF switch located on the cooling unit.